



HAWAII | Honolulu

PHNL/HNL

N21° 19' 07.287" / W157° 55' 20.666"
08L/26R 12,300 ft. x 150 ft.

Honolulu International Airport

13 ft. 011° E 00:01-23:59 -10 AVGAS/JET
HIRL ILS RNAV AOE

Company name: Air Service Hawaii
Main office: Honolulu, Hawaii
ICAO: PHNL
Additional offices: Hilo / PHTO, Kahului / PHOG, Kona / PHKO, Lanai / PHNY, Lihue / PHLI
Locations served: All of Hawaii
Radio frequency: 128.950 MHz
SITA: N/A
Manager: Rob Morris
Phone: +1 808 839 5003
Mobile: +1 808 479 2405
Fax: +1 808 836 2117
E-mail: honolulu@universalaviation.aero
Web: universalaviation.aero

With Universal Aviation in Honolulu, you...

Go Confident

- 24/7 staff availability
- Industry-leading training and audit system
- NATA Safety First certified

Go Convenient


- Executive air crew hotel transfer service
- Hotel reservations, deep sea fishing arrangements, helicopter tours, yacht and scuba charters
- Ground transport/shuttle service
- VIP passenger lounge

Go Competitive

- Competitive handling rates billed directly by this Universal Aviation location or through your Universal® account
- Attractive fixed payment terms through UVair®

*NATA Safety 1st is a registered trademark of the National Air Transportation Association.

Honolulu International Airport



Universal Aviation

A Parking areas

P Passenger meeting areas

See next page for driving directions.

Ground support capabilities

- On-site U.S. customs, immigration, and agriculture inspections
- Jet A and AvGas fueling service
- Pre-flight planning
- Full-color weather folios
- Bodyguard/armed guard aircraft security service arrangements (advance notice required)
- Aircraft storage and parking
- GPU, lavatory service and potable water
- Cabin cleaning, exterior washing, and polishing
- Gourmet crew catering
- Our house specialty - Mai Tai reception
- Fresh flower lei greeting
- Executive air crew hotel transfer service
- Hotel reservations
- Ground transport/shuttle service
- VIP passenger lounge
- Complete on-site laundry facility
- Deep sea fishing arrangements
- Helicopter tours
- Yacht and scuba charters
- Credit available

Flight Support

- RVSM: N/A
- ACAS/TCAS II: N/A
- ICAO Annex 16, Chapter II: N/A
- RNP 5 Airspace: N/A
- 8.33 MHz Channel Spacing: N/A
- Airport Fire Protection Category: PHNL: E
- ICAO flight plans do not remain in system



HAWAII | Honolulu


PHNL/HNL

N21° 19' 07.287" W157° 55' 20.666"
08L/26R 12,300 ft. x 150 ft.

Honolulu International Airport

13 ft. 011° E 00:01-23:59 -10 AVGAS/JET
HIRL ILS RNAV AOE

City view



Airport view



Driving directions

Directions to airport

- From Fort de Russy Military Reservation

Head southeast on Kalakaua Avenue. Turn left at Kapahulu Avenue. Turn left onto Waiālae Ave and take the ramp onto Lunalilo Hwy West (I-1). Take exit 16 toward the Airport. Keep left and follow signs to the Terminal.

Directions to office

- Main Thoroughfares:

Take the H-1 Freeway eastbound and exit at the airport. Take a right on Aolele Street and then a right on Lagoon Drive. Take a final right on Nakolo Place to Air Service Hawaii.

- From the Honolulu International Airport:

Travel north on Rodgers Boulevard, turning right onto the N. Nimitz Highway. Take a right at Lagoon Drive, then a right at Nakolo Place to reach Air Service Hawaii.

- From Waikiki:

Take a left toward and then onto Ala Wai Boulevard, turning right on McCully Street. Turn left on Dole Street and left again on Alexander Street. Travel up the ramp onto IH-1 West and take exit 18 - Nimitz Highway. After merging onto N. Nimitz Highway, turn left at Lagoon Drive and right onto Nakolo Place to reach Air Service Hawaii.

Facility address

Air Service Hawaii
95 Nakolo Place
Honolulu International Airport
Honolulu, Hawaii 96819
USA

Manager: Rob Morris

Phone: +1 808 839 5003

Mobile: +1 808 479 2405

Fax: +1 808 836 2117

E-mail: honolulu@universalaviation.aero

Web: universalaviation.aero