



## SINGAPORE

### WSSL/XSP

N01° 25' 01.02"/E103° 52' 03.55"  
21/03

### Seletar International Airport

36 ft. 000° E 24 w/R  
5,223 ft. x 151 ft.

+8  
MIRL

AVGAS (WSSL) / JET (WSSS)  
AOE

**Company name:** Universal Singapore Airport Services Pte. Ltd.

**ICAO:** WSSL

**Locations served:** All of Singapore

**Radio frequency:** 131.025 MHz

**SITA:** XSP00UV

**Manager:** Yvonne Chan

**Phone:** +65 64 844878

**Mobile:** +65 96 394868

**Fax:** +65 64 844879

**E-mail:** [singapore@universalaviation.aero](mailto:singapore@universalaviation.aero)

**Web:** [universalaviation.aero](http://universalaviation.aero)

### With Universal Aviation in Singapore, you...

#### Go Confident

- 24/7 staff availability with extensive experience and in-depth knowledge of the Singapore aviation environment
- Experienced in supporting special-purpose operations like demonstration flights and experimental flights throughout Singapore
- NATA Safety 1st certified
- Industry leading training and audit system


#### Go Convenient

- Dedicated passenger and crew lounge with wireless internet and printing facilities
- Conference room availability for meeting requirements
- Coordination of permits and handling set-up in regional countries available
- Coordination of ground handling plus transportation, accommodation arrangements, catering, dish-washing, and laundry services

#### Go Competitive


- Competitive handling rates billed directly by this Universal Aviation location or through your Universal<sup>®</sup> account
- Attractive fixed payment terms through UVair<sup>®</sup>

### Seletar International Airport



**A** Parking areas

**P** Passenger meeting areas

 See next page for driving directions.

### Ground support capabilities

- Fast clearances for customs, immigration, and quarantine
- Private facility separate to main airport terminal
- Private passenger and crew lounge with complimentary Wi-Fi access
- Complimentary beverages
- Shower facilities
- Ramp transfers for crew and passengers in our own well-maintained 10-seat passenger buses
- Passenger and crew transfer coordination
- Catering coordination and delivery to the aircraft
- Fueling coordination, ensuring the supplier is on time to the aircraft
- Ramp marshalling, chocking and coning of the aircraft, conforming to safety procedures
- Full baggage handling – offload, onload and delivery
- Aircraft lavatory services
- Aircraft water services
- Hotel accommodation booking assistance
- Full supervision of ground handling services at Changi International Airport
- Check AIP for seasonal route variations May thru November

### Flight Support

- **RVSM:** Implemented November 2001; airspace between FL310-410 inclusive
- **ACAS/TCAS II:** Effective 01 Jan 2005, all turbine engine aircraft with MTOW 5,700kg or more or authorized to carry 19 or more passengers must be equipped with ACASII
- **ICAO Annex 16, Chapter II:** Singapore AIC No. 36/2002, phase out date for Chapter II aircraft is deferred to 01 Apr 2003. A subsonic jet aircraft, unless otherwise exempted, is not permitted to operate in Singapore unless it possesses a noise certificate stating that it meets the noise standards of ICAO Annex 16, Volume 1, Chapter 3, or equivalent. The noise certificate may also take the form of a suitable statement contained in another document approved by the State of Registry of the aircraft
- **RNP 5 Airspace:** No
- **8.33 MHz Channel Spacing:** Not required as of 2002
- **Airport Fire Protection Category:** 6 (No facilities for foaming of runway)
- **ICAO flight plans remain in system for 60 minutes after ETD**



## SINGAPORE

### WSSL/XSP

N01° 25' 01.02"/E103° 52' 03.55"  
21/03


### Seletar International Airport

36 ft. 000° E 24 w/R  
5,223 ft. x 151 ft.


+8  
MIRL

AVGAS (WSSL) / JET (WSSS)  
AOE

#### City view



#### Airport view



#### Driving directions

##### Directions to airport

On the Tampines Expressway, exit at Jalan Kayu and enter Seletar Airbase. On Piccadilly Circus, turn left onto Edware Road and make the first left into West Camp Road. At Seletar West Camp Circus, continue onto West Camp Road. Drive on until you see the Seletar Airport Passenger Terminal on your right. Universal Aviation<sup>sm</sup> is located adjacent to the Airport Terminal.

##### Facility address

Universal Aviation  
Building 553  
West Camp Road  
Seletar International Airport  
Singapore 797763

**Manager:** Yvonne Chan

**Phone:** +65 64 844878

**Mobile:** +65 96 394868

**Fax:** +65 64 844879

**E-mail:** [singapore@universalaviation.aero](mailto:singapore@universalaviation.aero)

**Web:** [universalaviation.aero](http://universalaviation.aero)